

FES9280

Fully IP67 Fanless Embedded System
Intel 6th Generation Skylake Core i7 Processor
-20°C to 60°C Wide Range Working Temperature

User Manual

Declaration

Please read this chapter with some important notice before operations.

FCC Regulation Statement



This device complies with part 15 FCC rules.
Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class “a” digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Copyright Notice

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

Disclaimer

We reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. We assume no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. We make no representation or warranty that such application will be suitable for the specified use without further testing or modification.

Customer Service

The user guide includes simple debug and trouble shooting, for system crack or serious damage, please contact with your distributor, sales representative, the customer service center for technical support if you need additional assistance. You may have the following information ready before you call:

Product serial number

Peripheral attachments

Description of complete problem

The exact wording of any error messages

In addition, free technical support is available from our engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products. Please do not hesitate to call or e-mail us.

Safety Instructions

Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

Please read these safety instructions carefully.

- Please keep this user's manual for later reference.
- Please disconnect this equipment from any AC outlet before cleaning. Do not use acid or caustic liquid or spray detergents for cleaning. The good option is to use a damp cloth.
- Do not touch the LCD panel surface with sharp or hard objects.
- For pluggable equipment, the power outlet must be installed near the equipment and must be easily accessible.
- Place this equipment on a reliable surface during installation. Dropping it or letting it fall could cause damage..
- Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- All cautions and warnings on the equipment should be noted.
- If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient over-voltage.
- Never open the equipment. For safety reasons, only qualified service personnel should open the equipment.

Getting Started

The design allows you to use it in harsh environments – places you would not take with normal commercial grade. The mechanical is designed to be special environment in various kind of Military sort of heavy duty application.

This chapter tells you will find instructions when you are ready to use it :


- Unpacking
- Installation
- Cable Connection

2-1 Unpacking


This Equipment is suitable to use in IP66 / IP67 extremely tough environment normally outdoor, outfield, non-human adapted place. Before the procurement of it, please check with sales representative for functionality and signal which are adequate to communicate to your peripheral equipment or local devices. We do not actively provide the cable set in the accessory list, but we are able to make the cable with required length, the plugs at opposite side, and the specified cable shielding.

Inside the carton are items as below,

1. MIL. Box PC x 1pc
2. Driver CD x 1pc
3. Pin assignment datesheet x 1pc
4. USB Stick for OS recovery (If OS ordered)
5. Cable Set (optional)
6. Opposite plug for I/O connectors (optional)



1 x Pin Assignment




1 x User Manuel CD
(Containing Spec. , Drawing,
Driver, Manuel)

Note: All connectors have protective plastic cap on it, please take it away before to use.


2-2 Installation

The box has 4 thread holes at bottom for locking down to the wall / table, each thread hole is with $\phi 6$ in diameter, and 10mm in depth which was designed to avoid resonant and anti-vibration /shock together with the locking fixture. The L x W of the thread is 85 x 200 mm. Please refer to the drawings as below,



We also provide the add-on bracket for VESA mount or Din rail mount needed.

At back side of connectors there's a door for 1 bay removable storage, please loose 2 locking screws at both side, take the front door away. The space is for 1 x 2.5" SSD storage, the bus speed is connected to SATA I/II.




2-3 Cables Connections

Before to plug the cable and supply the power to it, please double check the Pin assignment provided by your sales representative, make sure the correct connector and pin definition all in appropriate to the Box.


Default Pin definition and connectors:

1. J1: D38999/24WH53SN
2. J2: D38999/24WD55SN



J1 Pin Assignments :


Pin	Pin Name
A	24V
B	24V
C	GND
D	GND
E	GND



J2 Pin Assignments :

Pin	Pin Name	Interface
A	Data 2+	HDMI
B	Data 2-	
U	Data 1+	
V	Data 1-	
q	Data 0+	
r	Data 0-	
CC	Clock +	
s	Clock -	
C	GND	
W	SCL	
D	SDA	
X	DDC GND	
Y	Hot Plug Detect	
E	+5V	
DD	RED	
u	GREEN	
b	BLUE	
t	GND	
a	R,G,B_GND	
H	Hsync	
Z	SCL	
G	Vsynv	
F	SDA	

Pin	Pin Name	Interface
S	USB1_VCC	USB1
T	USB1_GND	
n	USB1_D-	
p	USB1_D+	USB2
AA	USB2_VCC	
BB	USB2_GND	
GG	USB2_D-	LAN
HH	USB2_D+	
P	TX_D1+	
R	TX_D1-	LAN
k	RX_D2+	
m	RX_D2-	
h	BI_D3+	LAN
z	BI_D3-	
N	BI_D4+	
M	BI_D4-	RS232
L	CD	
q	RXD	
y	TXD	RS232
FF	DTR	
w	GND	
f	DSR	RS422
x	RTS	
K	CTS	
e	RI	RS422
EE	TX-	
v	TX+	
c	RX+	RS422
d	RX-	
J	GND	



Operation

When using a device, be sure to read the instructions accompanying the device. This chapter provides detail hardware specification for more understanding to this Box PC

- Hardware specification
- BIOS Settings

3-1 Hardware Specification

Basic Configuration

Processor: 6th Generation Intel® Core™ U-series

- i7 6600U 2.6 GHz, Dual-Cores, Four Threads (default)
- i5 6300U 2.4 GHz, Dual-Cores, Four Threads (Option)
- i7 6600U: 4MB
- i5 6300U: 3MB

Features:

- * Intel® Turbo Boost Technology 2.02 (i5/i7 series only)
- * Intel® Advanced Vector Extensions 2.0 (Intel® AVX2)
- Intel® Hyper-Threading Technology
- Intel® Active Management Technology 11.0 (Intel® AMT 11.0, i5/i7 series only)
- Intel® Trusted Execution Technology (Intel® TXT)
- Intel® 64 Architecture
- Intel® Virtualization Technology (Intel® VT)
- Intel® Advanced Encryption Standard New Instructions (Intel® AES-NI)
- Enhanced Intel SpeedStep® Technology

I/O interface of Platform Controller Hub

- Integrated Serial ATA Host Controller
 - Data transfer rates up to 6.0 Gb/s (600 MB/s)
 - Integrated AHCI controller
- USB
 - xHCI Host Controller, supporting 2 SuperSpeed USB 3.0 ports
 - One EHCI Host Controllers, supporting 2 HighSpeed USB 2.0 ports
 - Supports wake-up from sleeping states S1, S3
 - Supports legacy Keyboard/Mouse software
- Power Management
 - Full support of ACPI C-states as implemented by the following processor Cstates:
- C0, C1, C1E, C3, C6, C7, C8, C9, C10
 - Enhanced Intel SpeedStep® Technology

System Memory Support

- Non-ECC, DDR3L/DDR3L-RS and LPDDR3 memory with dual SO-DIMM up to 16GB
- DDR3L/DDR3L-RS I/O Voltage of 1.35 1333 MT/s (PC3-10600), 1600 MT/s (PC3-12800)
- 64-bit wide channels

Integrated Graphics Controller

- Contains a generation 9 graphics core architecture (Intel® HD Graphics 520/510)
- Intel® QuickSync & Clear Video Technology HD Supportt
- Full Hardware Accelerated Video Decode: AVC/VC1/MPEG2/HEVC/VP8/JPEG.
- OpenGL4.4 and OpenCL2.1 support
- DirectX 12, DirectX 11.3, DirectX 11.2, DirectX 11.1, DirectX 10, DirectX 9 support
- Multi-display interfaces: VGA, HDMI on rear I/O, Dual Channel 24-bit LVDS
- Support Extend, Clone and Collage mode with multi-display device
- Dual Display:
 - Any two combination between: VGA, HDMI
- Analog RGB display (VGA) output up to resolution 1920 x 1200 with 60 Hz, or 2048 x 1152 @ 60Hz with reduced blanking.
- HDMI interface supports the HDMI 1.4a specification with audio up to 4096x2160 at 24 Hz

Gigabit Ethernet

- Port1: Integrated Intel 100 Series Chipset (MAC) + i219 GbE (PHY)
 - Integrated ASF Management Controller
 - 10/100/1000 BASE-T IEEE 802.3 specification conformance
 - Supports the Energy Efficient Ethernet (EEE) IEEE802.3az specification
 - Supports up to 9 KB jumbo frames (full duplex) * 802.1as/1588 conformance
- Port2(Optional) : i210 Gigabit Ethernet Controller
 - Flow Control Support compliant with the 802.3X Specification
 - Compliant with the 1 Gb/s IEEE 802.3 802.3u 802.3ab Specifications

Electrical Specifications

Power Requirement: Default 9~36V DC \pm 10% power input

Power Consumption:

– Typically, under circumstances under normal operation

w/i7 6600U: 30 W

w/i5 6300U: 25 W

– System idle mode

i7 6600U: < 9 W

i5 6300U: < 6 W

RTC Battery:

– Typical Voltage: 3.0 V

– Normal discharge capacity: 210 mAh

Operating temperature: -20~ 60°C

Operating Humidity: 5~ 95% Non-Condensing

Storage Temperature: Storage temperature: -40~85°C

Storage Humidity: Relative humidity: 95% @ 60°C

Vibration: 2.5G, 5~500Hz/XYZ , MIL-STD- 810F Method 514.5 Procedure I

Shock: 40G, 11ms, MIL-STD-810F Method 516.5 Procedure I

EMI/EMC: MIL-STD- 461F compliance

Turn on the computer and then press <F2> or to enter Setup menu. With the BIOS Setup program, you can modify BIOS settings and control the various system features. This chapter describes the basic navigation of the BIOS setup screens.



AMI's BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in battery-backed CMOS so it retains the Setup information when the power is turned off.

Main Setup

When you first enter the BIOS Setup Utility, you will encounter the Main setup screen. You can always return to the Main setup screen by selecting the Main tab. There are two Main Setup options. They are described in this section. The Main BIOS Setup screen is shown below.



The Main BIOS setup screen has two main frames. The left frame displays all the options that can be configured. Grayed-out options cannot be configured; options in blue can. The right frame displays the key legend.

Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.

System time / System date

Use this option to change the system time and date. Highlight System Time or System Date using the <Arrow> keys. Enter new values through the keyboard. Press the <Tab> key or the <Arrow> keys to move between fields. The date must be entered in MM/DD/YY format. The time must be entered in HH:MM:SS format.



Advanced BIOS Features Setup

Select the Advanced tab from this setup screen to enter the Advanced BIOS Setup screen. You can select any of the items in the left frame of the screen, such as CPU Configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screens is shown below. The sub menus are described on the following pages.

PCI Subsystem Settings



Enable ACPI Auto Configuration

Enable or disable BIOS ACPI auto configuration.

Enable Hibernation

Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

ACPI Sleep State

Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.


Lock Legacy Resources

Enables or Disables Lock of Legacy Resources.

S3 Video Repost

Enable or Disable S3 Video Repost.

AMT Configuration



Intel AMT

Enable/Disable Intel® Active Management Technology BIOS Extension.

BIOS Hotkey Pressed

Enable/Disable BIOS hotkey press.

MEBx Selection Screen

Enable/Disable MEBx selection screen.

USB Provisioning of AMT

Enable/Disable of AMT USB Provisioning.


PET Progress

User can Enable/Disable PET Events progress to receive PET events or not.

Watch Dog

Enable/Disable WatchDog Timer.

PCH-FW Configuration



PCH-FW Configuration

This page display all information about system ME FW.

ME Unconfig on RTC Clear State

Disabling this option will cause ME not to unconfigure on RTC clear.

ME State

Set ME to Soft Temporary Disabled.

Firmware Update Configuration

Configure Management Engine Technology Parameters.

Embedded Controller Configuration



EC Hardware Monitor

This page display all information about system Temperature/Voltage/Current.

Backlight Enable Polarity

This item allows users to set backlight mode.

1st LVDS Backlight control

This item allows users to switch Backlight Control for PWM or DC mode.

Power Saving Mode

This item allows users to set board's power saving mode when off.

Deep Sleep delay time

Set delay time for Deep Sleep mode.

Watch Dog Timer


This item allows users to select EC watchdog timer.

Trusted Computing




Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

S5 RTC Wake Settings



Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr::min::sec specified.

Serial Port Console Redirection



Console Redirection

This item allows users to enable or disable console redirection for Microsoft Windows Emergency Management Services (EMS).

Console Redirection

This item allows users to configuration console redirection detail settings.

CPU Configuration



Hyper Threading Technology

This item allows users to enable or disable Intel? Hyper Threading technology.

Active Processor Cores

This item allows users to set how many processor cores should be active.

Intel Virtualization Technology

This item allows users to enable or disable the intel virtualization technology.

Hardware Prefetcher

This item allows users to enable or disable the hardware prefetcher feature.

Adjacent Cache Line Prefetch

This item allows users to enable or disable the adjacent cache line prefetch feature.

CPU AES

Enable/Disable CPU Advanced Encryption Standard instructions.

Boot Performance mode

Select the performance state that the BIOS will set before OS handoff.

Intel® Speed Shift Technology

Enable/Disable Intel® Speed Shift Technology support.

Intel® SpeedStep™

Allows more than two frequency ranges to be supported.

Turbo Mode

Turbo Mode.


CPU C states

Enable or disable CPU C states.

CState Pre-Wake

Disable – to disable the CState Pre-Wake.

CPU Configuration



Hyper Threading Technology

This item allows users to enable or disable Intel? Hyper Threading technology.

Active Processor Cores

This item allows users to set how many processor cores should be active.

Intel Virtualization Technology

This item allows users to enable or disable the intel virtualization technology.

Hardware Prefetcher

This item allows users to enable or disable the hardware prefetcher feature.

Adjacent Cache Line Prefetch

This item allows users to enable or disable the adjacent cache line prefetch feature.

CPU AES

Enable/Disable CPU Advanced Encryption Standard instructions.

Boot Performance mode

Select the performance state that the BIOS will set before OS handoff.

Intel® Speed Shift Technology

Enable/Disable Intel® Speed Shift Technology support.

Intel® SpeedStep™

Allows more than two frequency ranges to be supported.

Turbo Mode

Turbo Mode.

CPU C states

Enable or disable CPU C states.

CState Pre-Wake

Disable – to disable the CState Pre-Wake.


Package C State limit

Package C State limit.

SW Guard Extension (SGX)

Enable/Disable Software Guard Extensions (SGX).

Intel TXT Information



Intel TXT Information

Display Intel TXT information.

SATA Configuration



SATA Controller

Enable / Disable SATA Device.

SATA Mode Selection

Determine how SATA controller operate.

Aggressive LPM Support

Enable PCH to aggressively enter link power state.

Port 1 / Port 2 / mSATA Port

Enable / Disable Serial ATA Port 1 / Port 2 / mSATA Port.

SATA Device type

Identify the SATA port is connected to Solid State Drive or Hard Disk Drive.

Network Stack Configuration



Enable/Disable UEFI Network Stack.

CSM Configuration



CSM Support

Enable/Disable CSM Support.

GateA20 Active

UPON REQUEST - GA20 can be disabled using BIOS services. ALWAYS - do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.

Option ROM Message

BIOS Set display mode for Option ROM.

INT19 Trap Response

BIOS reaction on INT19 trapping by Option ROM: IMMEDIATE - execute the trap right away; POSTPONED - execute the trap during legacy boot.

Boot option filter

This option controls Legacy/UEFI ROMs priority.

Network

Controls the execution of UEFI and Legacy PXE OpROM.

Storage

Controls the execution of UEFI and Legacy Storage OpROM.


Video

Controls the execution of UEFI and Legacy Video OpROM.

Other PCI devices

Determines OpROM execution policy for devices other than Network, Storage, or Video.

USB Configuration



Legacy USB Support

Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.

XHCI Hand-off

This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

USB Mass Storage Driver Support

Enable/Disable USB Mass Storage Driver Support.

Port 60/64 Emulation

Enables I/O port 60h/64h emulation support. This should be enabled for the complete USB keyboard legacy support for non-USB aware OSES.

USB transfer time-out

Time-out value for control, Bulk, and interrupt transfers.

Device reset time-out

USB mass storage device start unit command time-out.

Device power-up delay

Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

IT8768E Super I/O Configuration



Serial Port 1 Configuration


Set Parameters of Serial Port 1 (COMA).

Serial Port 2 Configuration

Set Parameters of Serial Port 2 (COMB).

Chipset

Select the Chipset tab from the setup screen to enter the Chipset BIOS Setup screen. You can display a Chipset BIOS Setup option by highlighting it using the <Arrow> keys. All Plug and Play BIOS Setup options are described in this section. The Plug and Play BIOS Setup screen is shown below.



Graphics Configuration



Graphics Turbo IMON Current

Graphics turbo IMON current values supported.

Aperture Size

Select the Aperture Size.

DVMT Pre-Allocated

Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.

DVMT Total Gfx Mem

Select DVMT 5.0 Total Graphic Memory size used by the Internal Graphics Device.

PM Support

Enable/Disable PM Support.

PAVP Enable

Enable/Disable PAVP.

Memory Configuration Options



Maximum Memory Frequency

Maximum Memory Frequency Selections in Mhz.

Max TOLUD

Maximum Value of TOLUD.

SA GV

System Agent Geyserville.

SA GV Low Freq

System Agent Geyserville. Set frequency for low point.


Energy Performance Gain

Enable/disable Energy Performance Gain.

Memory Remap

Enable/Disable Memory Remap above 4GB.

PCH-IO Configuration



USB Configuration

USB Configuration Settings.

BIOS Security Configuration

BIOS Security Configuration Settings.

HD Audio Configuration

HD Audio Subsystem Configuration Settings.

SB Porting Configuration

SB Porting Configuration Settings.

Mini PCIE/mSATA Selection

Select to enable Mini PCIE or mSATA for connector (CN25).

PCH LAN Controller

Enable or Disable onboard NIC.

LAN Option ROM

Enable or Disable onboard LAN's PXE option ROM.

Wake on LAN

Enable or Disable Integrated LAN to wake the system from S5.

Onboard LAN2 Controller

Enable or Disable onboard NIC.

LAN Option ROM

Enable or Disable onboard LAN's PXE option ROM.

PCIE Wake

Enable or Disable PCIE to wake the system from S5.

High Precision Timer

Enable or Disable High Precision Event Timer.

State After S3

Specify what state to go to when power is re-applied after a power failure (G3 state).

Boot



Setup Prompt Timeout

Number of seconds that the firmware will wait before initiating the original default boot selection. A value of 0 indicates that the default boot selection is to be initiated immediately on boot. A value of 65535(0xFFFF) indicates that firmware will wait for user input before booting. This means the default boot selection is not automatically started by the firmware.

Bootup NumLock State

Select the keyboard NumLock state.

Quiet Boot

Enables or disables Quiet Boot option.

Boot Option #1

Sets the system boot order.

Fast Boot

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

New Boot Option Policy

Controls the placement of newly detected UEFI boot options.