



RM 6193


6U Rackmount 19" LCD Monitor

# Installation Guide

*RM 6193: 6U Rackmount 19" LCD Monitor*

# RM 6193

## 6U Rackmount 19" LCD Monitor



1. Find the property position and size to screw rack mount front bezel onto the server rack mount first.
2. Lift and push the rack mount monitor into the rack cabinet, and screw between bracket and rack mount monitor with screws.