

# PMH8170

17" 1280 x 1024 LCD Monitor  
Open Frame Metal Construction  
1000-nit High Brightness LCD

## User Manual

## Legal Information

First English printing, October 2002

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

## Safety Instructions

**Please read all of these instructions carefully before you use the device. Save this manual for future reference.**

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the equipment is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labeled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

## What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - Repair or attempted repair by anyone not authorized by us.
  - Any damage of the product due to shipment.
  - Removal or installation of the product.
  - Causes external to the product, such as electric power fluctuation or failure.
  - Use of supplies or parts not meeting our specifications.
  - Normal wear and tear.
  - Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

## Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

## Contents

### < Part. 1 > PMH 8170

1.1	Package Content	P.1
1.2	Structure Diagram & Dimension	P.2 - 3
1.3	Mounting Hardware & Installation	P.4

### < Part. 2 > Specifications I OSD

2.1	Product Specifications	P5 - 6
2.2	On-screen Display Operation ( OSD )	P.7

### < Part. 3 > Options

3.1	Option Table	P.8
3.2	3G / HD / SD- <b>SDI</b> Broadcast-grade input	P.9
3.3	<b>MCS</b> Multi-display control solution	P.10
3.4	<b>AD2.2</b> Upgrade : HDMI, S-Video + BNC & Audio	P.11
3.5	<b>AD3.0</b> Upgrade : HDMI, DVI-D, S-Video + BNC & Audio	P.12
3.6	17" Touchscreen : Capacitive, Resistive	P.13
3.7	48V or 24VDC power	P.14
3.8	MIL-type or lockable connector	P.15
3.9	TV ( Analog )	P.16 - 17
3.10	Auto / switch dimming	P.18

## Before Installation

- It is very important to mount the equipment in a suitable cabinet or on a stable surface.
- Make sure the place has a good ventilation, is out of direct sunlight, away from sources of excessive dust, dirt, heat, water, moisture and vibration.

## Unpacking

The equipment comes with the standard parts shown in package content. Check and make sure they are included and in good condition. If anything is missing, or damaged, contact the supplier immediately.

## How To Clean Your LCD Monitor



### Caution :

- To avoid the risk of electric shock, make sure your hands are dry before unplugging your monitor from or plugging your monitor into an electrical outlet.
- When you clean your monitor, do not press down on the LCD screen. Pressing down on the screen can scratch or damage your display. Pressure damage is not covered under warranty.
- Use only cleansers made specifically for cleaning monitors and monitor screens. Cleansers not made to clean monitors and monitor screens can scratch the LCD display or strip off the finish.
- Do not spray any kind of liquid directly onto the screen or case of your monitor. Spraying liquids directly onto the screen or case can cause damage which is not covered under warranty.
- Do not use paper towels or abrasive pads to clean your monitor. Using an abrasive pad or any wood based paper product such as paper towels can scratch your LCD screen.

## Cleaning Your Monitor

To clean your LCD safely, please follow these steps :

- ① Disconnect the power cord.
- ② Gently wipe the surface using a clean, dry microfiber cloth. Use as little pressure as possible.

## Cleaning Tough Marks and Smudges

To remove tough marks and smudges, please follow these steps :

- ① Disconnect the power cord.
- ② Spray a small amount of non-abrasive cleanser on a microfiber cloth.



**Caution : Do not spray or apply any liquids directly onto the monitor. Always apply the solution to your microfiber cloth first, not directly on the parts you are cleaning.**

- ③ Gently wipe the surface. Use as little pressure as possible.
- ④ Wait until your monitor is completely dry before plugging it in and powering it up.

**< Part 1 >**


**< 1.1 > Package Content - PMH 8170**




**Standard I/O**



**AD2.2 upgrade I/O**




**AD3.0 upgrade I/O with advanced features**



- An abundance of input connections that include HDMI, DVI-D, VGA, S-Video + BNC and audio
- On-chip Faroudja® DCDi Cinema processing
- Casing dimensions will be changed


## < 1.2 > Structure Diagram-PMH 8170




Model	Product Dimension (W x D x H)	Packing Dimension (W x D x H)	Net Weight	Gross Weight
PMH8170	436 x 58 x 354 mm 17.2 x 2.3 x 13.9 inch	615 x 113 x 523 mm 24.2 x 4.4 x 20.6 inch	5.5 kg 12 lbs	7.5 kg 17 lbs

# < 1.2 > Dimension - PMH 8170


Front View




Side View



Rear View




Bottom View




UNIT : mm  
1mm = 0.03937 inch

## < 1.3 > Installation - PMH 8170

### ( I ) Universal mount



### ( II ) VESA mount ( 100\*100mm )



Hardware and M4\*4 pcs for VESA mounting are not provided

## < Part 2 >

### < 2.1 > Product Specifications

<b>Mechanical Design</b>		<b>PMH 8170</b>	
	Front Panel	-	
	Rear Casing	Dark grey, RAL 7037	
	VESA Mounting	100 x 100mm	
	Other Mounting	Universal mount	
Protection	-		

<b>LCD Panel</b>	Panel Size ( diagonal )	17-inch TFT color LCD	
	Display pixel ( dots x lines )	1280 x 1024	
	Brightness ( typ. )	1000	
	Contrast Ratio ( typ. )	1000:1	
	Color	16.7 M	
	Viewing Angle ( L/R/U/D )	85/85/80/80	
	Response Time ( ms )	5	
	Dot pitch ( mm )	0.264	
	Display Area ( mm )	337.92H x 270.33V	
	Surface treatment	Anti-glare	
	Surface hardness	3H	
	Backlight Type	LED	
	MTBF ( hrs )	50,000	

<b>Video Connectivity</b>	Analog	VGA	Analog 0.7Vp-p

<b>Power</b>	Power Supply	Range	Auto-sensing 100 to 240VAC, 50/60Hz
	Power Consumption	Screen display ON	35W or less
		Power saving mode	4W or less
		Power button OFF	1W or less

<b>Regulatory</b>	Safety Approval	FCC & CE
-------------------	-----------------	----------


<b>Environmental Conditions</b>	Operating	Temperature	0 to 50°C degree
		Humidity	20~90%, non-condensing
	Storage	Temperature	-5 to 60°C degree
		Humidity	5~90%, non-condensing
		Shock	10G acceleration (11ms duration)
		Vibration	5~500Hz 1G RMS random

<b>Physical Specification</b>	Product ( W x D x H )	436 x 58 x 354 mm 17.2 x 2.3 x 13.9 inch
	Packing ( W x D x H )	615 x 113 x 523 mm 24.2 x 4.4 x 20.6 inch
	Net Weight	5.5 kgs / 12.1 lbs
	Gross Weight	7.5 kgs / 16.5 lbs


<b>Applicable Format</b>	VGA Input	PC Signal	1280 x 1024 x 60 / 75Hz
			1280 x 960 x 60Hz
			1280 x 760 x 60 / 75Hz
			1152 x 864 x 75Hz
			1024 x 768 x 60 / 70 / 75Hz
			848 x 480 x 60Hz
			800 x 600 x 60 / 72 / 75Hz
			720 x 400 x 70Hz
			640 x 480 x 60 / 72 / 75Hz
			640 x 400 x 70Hz
640 x 350 x 70Hz			

## < 2.2 > On-screen Display Operation ( OSD )

- ◊ Power light
- Green = On
- Orange = Power saving




Membrane Switch	Function
	Power on / off LCD
	Display the OSD menu
	Scrolls through menu options and adjusts the displayed control (To auto adjustment by pressing the button  for 5 seconds)
	Exit the OSD screen Toggle analog, digital & video connection (DVI-D and video options only)



### OSD Configuration Page



**Image:**  
for the brightness, contrast, color temp, red, green, and blue



**Geometry:**  
for the auto adjust, H position, V position, phase and clock



**Video:**  
for the colour, tint, sharpness, noise reduction, DCDi and TV Setup



**Audio:**  
for volume, bass, treble, balance, AVL and mute



**Misc:**  
for the language, OSD position, graphic mode, ratio, reset and timer

## < Part 3 > Options

### < 3.1 > Option Table

Options	APH	PMH
SDI ***	✓	✓
HDMI * or DVI-D	✓	✓
S-Video * + Composite ( BNC )	✓	✓
Audio	✓	✓
Touchscreen	✓	✓
MCS multi-display control ***	✓	✓
DC Power	✓	✓
MIL-type / lockable connector	✓	✓
TV ( Analog ) *	✓	✓
Auto / switch dimming	✓	✓



#### \*\*\* About SDI and MCS

- ( 1 ) The user can only select either SDI or MCS inputs.
- ( 2 ) For SDI input, the AD board will be upgraded to version 3.0, and this comes standard with HDMI, DVI-D, VGA, S-Video, BNC, audio inputs and RC-2 remote controller.

#### \* About HDMI and DVI-D

- ( 1 ) For AD2.2 upgrade, only HDMI is provided.
- ( 2 ) If the user needs HDMI and DVI-D, AD3.0 upgrade can be applied.

#### \* Remote Controller

- ( 1 ) AD2.2 upgrade comes with RC-1 remote controller.
- ( 2 ) AD3.0 upgrade or TV option comes with RC-2 remote controller.


### < 3.2 > Options : 3G | HD | SD-SDI input



Acnodes' SDI input is an ideal solution for the broadcast- grade video and high resolution CCTV market.

Designed for use with Full HD 1080p and ultra high resolution 1920 x 1200 LCD displays, Acnodes provides a SDI input module without using additional space or power and it comes standard with a 2-year warranty

#### SDI



\*\*\* For **SDI** option, the AD board will be upgraded to AD3.0, and this comes standard with HDMI, DVI-D, VGA, S-Video, BNC, audio inputs and RC-2 remote controller ( please refer to P.23 )

<b>INPUT</b>	3G-SDI IN	BNC x1 / 0.8Vp-p ( 75 ohm )
	3G-SDI OUT	BNC x1 / Active through, equalized & relocked
<b>Standard Compliance</b>	Video	SMPTE 425M/ 274M/ 296M/ 125M ITU-R BT.656
	Audio	SMPTE 299M/ 272M-C
<b>Compatible Video Format</b>	3G-SDI	1080p @60 / 50Hz, 4:2:2
		1080p @30 / 25 / 24Hz, 4:4:4
		1080i @60 / 50Hz, 4:4:4
		720p @60 / 50Hz, 4:4:4
HD-SDI	1080p @30 / 25 / 24Hz, 4:2:2	
	1080i @60 / 50Hz, 4:2:2	
	720p @60 / 50Hz, 4:2:2	
SD-SDI	480i @60Hz, 4:2:2	
ITU-R BT.656	576i @50Hz, 4:2:2	
<b>Compatible Audio Format</b>	3G-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized Video
	HD-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized Video
	SD-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized / Asynchronized Video
<b>Max. Transmission Distance 75 ohm coaxial cable</b>	3G-SDI	150m at 2.97Gb/s
	HD-SDI	250m at 1.485Gb/s
	SD-SDI	480m at 270Mb/s

## < 3.3 > Options : MCS

### MCS ( Multi-display Control )





More control is always good. Especially when it is necessary and easy. Acnodes provides MCS solution to control the **OSD** of various LCD display up to 64 units.

The RS-232C is used for the communication between the PC and the first display via a 15 feet serial cable while the CAN bus is used for the various LCD displays cascade together via CAT 5/6 cable, and daisy chain up to 1,000 meters.

Designed for use with various LCD displays, Acnodes provides a MCS input module without using additional space or power and it comes standard with a 2-year warranty.

### MCS



## < 3.4 > AD2.2 Upgrade Options :

- HDMI
- S-Video + BNC
- Audio




**AV** : S-Video + Composite (BNC)

**HDMI** : HDMI 1.1, CEA-861-D

**Audio** : 3.5mm audio jacks for audio in & out, and 2W + 2W speakers

\*\*\*


**AD2.2 upgrade option comes with RC-1 remote controller x 1.**



①	<b>POWER</b>	Sw itches on or off the TV
②	<b>MUTE</b>	Turn on or off the speaker
③	<b>AV</b>	Sw itch toAV mode
④	<b>0- 9</b>	Select channels. For channel numbers 10 and above, enter the second digit within two seconds.
⑤	<b>V + -</b>	Increase or decrease the speaker volume
⑥	<b>CH+  -</b>	Increase or decrease the channel number
⑦	<b>MENU</b>	Display the men u on the screen or go to the previous menu
⑧	<b>AUTO</b>	For auto searching
⑨	<b>-  -</b>	For setting one or tw o input digit

## < 3.5 > AD3.0 Upgrade Options :

- **HDMI**
- **DVI-D**
- **S-Video + BNC**
- **Audio**



**AV** : S-Video + Composite (BNC)

**HDMI** : HDMI 1.1, CEA-861-D

**DVI-D** : DVI-D TMDS single link

**Audio** : 3.5mm audio jacks for audio in & out, and 2W + 2W speakers

\*\*\*

( 1 ) AD3.0 upgrade option comes with RC-2 remote controller x 1

( 2 ) Casing dimensions will be changed

## < 3.6 > Options : Touchscreen & driver




### 17" USB Touchscreen Specification

Model	TRB e-Resistive	TCB e-Capacitive
Technology	5-Wire Resistive	Capacitive
Touch Point	Single	Single
Method	Stylus or Finger	Finger
Activation Force	= 50g / Stylus=R0.8	= 50g
Durability	35 million touches	300 million touches
Response Time	15 ms	20 ms
Optical Transmittance	80% ± 3%	93% ±2%
Surface Hardness	3H	9H
Haze	8% ± 3%	7%
Glass	1.4 ±0.2 mm	2.8 mm ±10%
Connector	USB Type A	
Compatibility	Windows 7 / XP / Vista, Linux	

- USB touchscreen package includes 1 x 6ft USB cable, quick reference guideline and CD disc
- For detailed information, please refer to the attached CD disc
- As the touchscreen unit is not made of toughened glass, please handle it carefully

### USB Touchscreen



**Please follow the below steps to setup the touch screen:-**

**Step 1.** Run the bundled CD disc

**Step 2.** Double click the Setup.exe

**Step 3.** Follow the installation instruction to finish the setup

**Step 4.** After installation, run the TouchKit program & the “4 point calibration”



Please do the initial calibration after the first setup



### < 3.7 > Options : DC Power

Model	24V	48V
<b>Input rating</b>		
Input voltage:	24-Volt	48-Volt
Input range:	18 ~ 36V	36 ~ 75V
Input current		
- No load	50 mA	50 mA
- Full load	4880 mA	2442 mA
<b>Output rating</b>		
Output voltage:	12-Volt	12-Volt
Output current:	8.3A	8.3A
<b>Efficiency</b>	85%	86%

### < 3.8 > Options : MIL-type or Lockable Connector


	Input	Part no.	MIL Standard
MIL - type Connector	DC Power *** ( Male )	MS3470W8-33P 	MIL - DTL - 26482
	VGA *** ( Male )	MS3470W14-15P 	MIL - DTL - 26482

\*\*\* There are several additional MIL DC and VGA connector types with varying design characteristics to meet cost considerations and to provide users with the most design flexibility possible. For more information, please contact us.

	Input	Part no.	Standard
Lockable Connector	DC Power ( Male )	YM-Ext-461CP001 	D-type 3W3
	USB	LUSB - A111 - 00 	-

\*\*\* MIL - type or Lockable connectors above can be integrated with our LCD displays. Sale service just for connectors not provided.

### < 3.9 > Options : TV ( Analog )




\*\*\* For TV option :

( 1 ) The AD board comes standard with HDMI, VGA, S-Video, BNC, audio inputs and RC-2 remote controller.


( 2 ) Casing dimensions will be changed.

# How to Use RC-2 Remote Controller




①	<b>INPUT</b>	Select the source
②		Switches on or off the TV
③	<b>0 - 9</b>	Only use in TV mode. Select channels. For channel numbers 10 and above, enter the second digit within two seconds.
④	<b>AUTO</b>	Auto adjust
⑤	<b>MENU</b>	Display the menu on the screen or go to the previous menu
⑥	? / ? / ? / ? / <b>ENTER</b>	Go to the upper menu or select the previous value / Go to the next menu or select the next value / Decrease the setting value / Increase the setting value or enter to the select item setting Enter to the select item settings or excude the setting
⑦	<b>BACK</b>	Back to previous value
⑧	<b>MUTE</b>	Turn on or off the speaker
⑨	<b>Vol + I -</b>	Increase or decrease the speaker volume
⑩	<b>CH + I -</b>	For TV model only, increase or decrease the channel number
⑪	<b>FREEZE</b>	Reserve for OEM model
⑫	<b>- I --</b>	For setting input single or double digits
⑬	<b>ASPECT</b>	Adjust the screen size
⑭	<b>SELECT</b>	To select the existing item
⑮	<b>SLEEP</b>	Select the sleeping time
⑯	<b>EXIT</b>	Exit the menu or cancel
<b>PIP functions</b>		
⑰	<b>PIP</b>	Picture in picture
⑱	<b>PIP AUDIO</b>	To set the audio of in PIP mode
⑲	<b>POSITION</b>	To set the screen position in PIP mode
⑳	<b>SOURCE</b>	PIP Source
㉑	<b>SWAP</b>	Sw ap screen in PIP mode

## < 3.10 > Options : Auto Dimming



① DA-01 Light sensor on OP model  
(66cm from AD board to sensor end)




② DA-01 Light sensor on AP model

DA-01 light sensor will be installed on the display front panel when auto dimming is ON in OSD menu. Then the brightness of display is changed according to its environmental brightness.

Once the auto dimming is ON, users cannot adjust brightness in OSD.

Steps : OSD Menu > Picture > Auto Dimming > ON

### Light Sensor Operation Range



## Options : Switch Dimming

DS-01 is a IP54 dimming knob installed on the display front panel. The display can support hyper dimming function to adjust brightness from nearly 0% to 100% via a easy to use VR knob.

Dimming Knob

